


CS 50 & 75 Exploded View



Item	Part No.	Description	Number Per Tool	Item	Part No.	Description	Number Per tool
1	9550	Handle	1	19	1143	Front end complete	1
2	9554	Isolator body	1	20	1144	Silencer Guard	1
3	9553	Oil Cap & Retainer	1	21	1143A	Front End Cap	1
4	9555	Isolator Nozzle	1	22	54160	Front cap screws	3
5	9559	Oil Control Ball	1	23	54160	Screws—Nosepiece	2
6	9334A	Spring	1	24	5045/5075	Nosepiece(1/2"-3/4")	1
7	9561	'O' Ring Large	2	25	1147	Centre Shaft	1
8	9560	'O' Ring Small	2	26	55516	Screws for above	2
9	9557	Détente Spring	1	27	1150	Link to Pistons	1
10	9556A	Lock Screw	1	28	1148	Top Piston	1
2 to 10	9552	Isolator Assembly		29	1152	Bottom Piston	1
11	51834	Roll Pin-Trigger	2	30	1147	Pin to Link	2
12	50034	Valve in Handle	1	31	1147	Pin to Pedestal	1
13	9502	Trigger	1	32	1153-5	Pedestal	1
14	9506	Filter/Gauze	1	33	5540	Screw-Handle/Front	8
15	9538	Gasket	2	34	5520	Screw-Front Lower	2
16	9507	Valve Unit	1	35	9560 & 9561	Isolator Seals	1
17	1141L	Body	1	36	W55	Serrated Washer	10
18	1142	Gasket—Front end	1	37	5068	Screw-Blade Grip	2